front side 正面

back side 反面

INNO+IIT



TRUE WIRELESS STEREO EARBUDS

USER MANUAL

Product and accessories





Type-C Charging Cable *1




User manual *1

THANK YOU CARD

Thank you card*1

Description of product structure



1. MFB button 3. Earbuds indication (Touch panel)

(Microphone) 2. Power LED indicator 4. Charging port

Wearing method

Gently insert the earbuds into the ear then adjust the appropriate comfort.



Basic function

01 Power on, Wireless connection

-Follow the steps(Please confirm that your phone is built-in Bluetooth-function.)

a)Method 1: Open the charging case and take out the earbuds. The earbuds enter the pairing mode automatically while the indicator of one earbud flashes white light slowly, the other don't flash light, b)Method 2: If earbuds are power off outside the case, long press the MFB for 3s on both sides to turn them on.

2. Turn on Bluetooth-function on your device and select "INNO HIT TWS03" referring to your phone instructions. The indicator of earbuds turns off if the earbuds successfully paired.Pairing mode can just last 180 seconds.If you miss the pairing time,you need to restart the device and operate follow the procedural steps mentioned above.

a). INNO HIT TWS03 remembers previously connected devices. When turned on, earbuds attempts to reconnect to previously connected devices.

6. Don't iam the ports of the earbuds such as

charger port,LED port and microphone etc.

recommended to adjust the volume to the

after-sales staff in time rather than repair by

vourself.Otherwise.vou will accept without

7. In order to protect your hearing and

extend the speaker service life it is not

earbuds.please feel free to contact our

maximum level for a long time.

8. Whatever reasons damage the

b).INNO HIT TWS03 will disconnect when deviate the working range of Wireless. The earbuds will reconnect automatically if you come back to the range in 3 minutes.

02 Power off

a)Method 1: Put the earbuds into the charging case and close the case, they will automatically shut off.

b)Method 2: Long press the MFB for 5s on both sides to turn them off.

03 Answering incoming calls

Double tap the left or right MFB to answer incoming calls.

04 End the call

Double tap the left or right MFB to end the current call.

05 Decline incoming call

Long press left or right MFB for 1s to reject a

06 One key for voice assistant

Both earbuds work: Triple tap the left MFB to activate voice assistant Single earbud work: Triple tap the MFB of working earbud.

07 Switch on/Switch off Game mode Triple tap the right MFB to switch on/switch off game mode.

08 Music playing

- 1. Play/Pause:Double tap the left or right
- 2. Previous song:Long press the left MFB for
- 3. Next song:Long press the right MFB for 1s. *Note:If only one earbud works,long press left or right MFB for 1s to switch to next song.

09 Charging

Charge the case using the Type-C cable connected to a computer or wall charger. When the case is charging, the orange light of the case flashes light slowly, and turns steady orange after fully

10 Mono mode (Take out any earbuds as a unilateral Wireless earbud.)

(Note:Single channel mode only needs to remove one of earbuds from the charging box,if two earbuds are removed before connection, the earbud will be used in TWS

mode by default and the TWS connection will be automatically realized.)

- 1. Take out one earbud from charge case, the earbuds automatically turn on and reconnect to previous connected devices.
- 2. Switch from one earbud to the other earbud when playing music,taking out the other earbud from the charging case and these two earbuds will connected automatically. Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes. (Note:Call mode is applicable.) 3. Please refer to the TWS mode for more

functions.

11 Restore factory settings If the earbuds can't pair frequently, please restore the factory settings. Open the charging case and take out the earbuds, press the MFB of the earbuds four times, the indicator of the earbuds flashes for 3 times, the earbuds will enter the pairing mode again, search the "INNO HIT TWS03" Wireless pairing name with the mobile phone and connect again.

Specification

Wireless Version:V5.3 Wireless Working Range:10M(without obstacles) Earbuds Battery:30mAh Charging Case Battery:300mAh Play Time:5H Talk Time:3.5H Case Charging Time: Approx.2H Speaker Size: Ф13mm*2 Speaker Frequency:20Hz~20kHz Input Voltage/Current:DC 5V/0.3A USB Port:Type-C

temperature.

- 1. Please follow the instruction to operate. 2. Please charge the earbuds with input
- power below 5V/1A,in order to protect the
- 3. Please store or use the earbuds in a normal temperature environment.
- 4. Please do not use this product near the water.Do not immerse this product in any liquid or splash any liquid on this product. 5. Please keep the earbuds from heat source, such as radiators, hot air regulators, stoves, or other heat generating

instruments. As it is not anti high

WARRANTY

after-sales service.

The INNO HIT warranty covers the product and its accessories against manufacturing defects (if any) for 2 years from the date of

The following situations are not covered by the warranty:

Unauthorized tampering, modifications or repairs to the product.

Physical damage to the product caused by abuse, handling, storage, installation, or testing, including use inconsistent with the user manual, documentation, or any other instructions provided with the Inno Hit product,

T. MANUFACTURING MALTA LTD

DECLARATION OF CONFORMITY

We declare under our sole responsibility, that the products

MODEL: HAVIT TWS TWS976 - INNO HIT TWS03-W and TWS03-B

Article	Standard	Test Report
3.2	ETSI EN 300 328 V2.2.2 (2019-07)	MTI230921017-01E1
3.1(b)	ETSI EN 301 489-1 V2.2.3 (2019-11 ETSI EN 301 489-17 V3.2.4 (2020-0	
3.1(b)	EN 55032:2015+A1:2020 EN55032:2015+A11:2020 EN 55035:2017+A11:2020 EN IEC 61000-3-2:2019+A1:2021 EN 61000-3-3:2013/A2:2021	MTI230921017-02E
3.1(a) SAI	R EN 62479:2010 EN 50663: 2017	MTi230921017-01E3
3.1(a) Saf	etyEN IEC 62368-1:2020+A11:2020	MTI230921017-03S

9

材质: 128g双铜纸双面印刷, 风琴折

印刷色号(Printing color number): C:0 M:0 Y:0 K:70

尺寸(Size): 55 X 77 mm